

				Tool changer																				
				Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	
				Order code No.	TYPE	140266 (140280)	140268 (140281)	140181 (140225)	140182 (140226)	140299 (140300)	140301 (140302)	140183 (140231)	140186 (140232)	140274 (140258)	140273 (140259)	140184 (140277)	140187 (140278)	140217 (140229)	140218 (140230)	140275 (140260)	140276 (140261)	140233	140234	140345 (140345)
		Order code No.		OX-SSB(N)	OX-SSB(N)I	OX-SB(N)	OX-SB(N)I	OX-WSB(N)	OX-WSB(N)I	OX-LB(N)	OX-LB(N)I	OX-LBF(N)	OX-LBF(N)I	OX-WLB(N)	OX-WLB(N)I	OX-SBY(N)	OX-SBY(N)I	OX-SBH(N)	OX-SBH(N)I	OX-SBS	OX-SBSI	OX-SBN-30	OX-LB(N)-30	OX-WLB(N)-30
Air option	Robot side	140294	OX-SSBA	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	
	Tool side	140295	OX-SSBIA	—	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	
	Robot side	140193	OX-SBA	—	—	○	—	—	—	—	—	—	—	—	—	○	—	○	—	—	—	○	—	
	Tool side	140194	OX-SBIA	—	—	—	○	—	—	—	—	—	—	—	—	○	—	○	—	—	—	—	—	
	Robot side	140251	OX-SBA1	—	—	○	—	—	—	—	—	—	—	—	—	○	—	○	—	—	—	○	—	
	Tool side	140252	OX-SBIA1	—	—	—	○	—	—	—	—	—	—	—	—	○	—	○	—	—	—	—	—	
	Robot side	140391	OX-SCA-10	—	—	○	—	—	—	—	—	—	—	—	—	○	—	○	—	—	—	○	—	
	Tool side	140392	OX-SCIA-10	—	—	—	○	—	—	—	—	—	—	—	—	—	○	—	○	—	—	—	—	
	Robot side	140195	OX-LBA	—	—	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—	—	—	○	
	Tool side	140196	OX-LBIA	—	—	—	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—	—	—	
	Robot side	140253	OX-LBA1	—	—	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—	—	—	○	
	Tool side	140254	OX-LBIA1	—	—	—	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—	—	—	
	Robot side	140287	OX-LBA3	—	—	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—	—	—	○	
	Tool side	140288	OX-LBIA3	—	—	—	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—	—	—	
Maintenance parts	Barbed joint	110623	LX0004-101	—	—	—	○	—	—	—	—	—	—	—	—	○	—	○	—	—	—	—	—	
		230116	XL0054-106A	—	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	
		230117	XL0054-206A	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	
		110722	LX0181-203	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	
	Steel ball	323000	φ6.35	—	—	○	—	○	—	○	—	○	—	○	—	○	—	○	—	—	—	○	○	
		310607	φ5.5	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	
	Coil spring	110649	L00999-420	—	—	○	—	○	—	—	—	—	—	—	—	○	—	—	—	—	—	—	○	
		185221	SAWANE5115	—	—	—	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—	—	○	
		110619	L00999-316	—	—	—	—	—	—	—	—	—	—	—	○	—	—	○	—	—	—	—	○	
		200223	UR5-10	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	
	Packing (Robot side)	184474	S6(C00503-A00X8)	—	—	○	—	○	—	○	—	○	—	○	—	○	—	○	—	—	—	○	○	
	Packing (Tool side)	271742	1ASS-5	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	
	Packing (Tool side)	110551	L00999-313	—	—	—	○	—	○	—	○	—	○	—	○	—	○	—	○	—	—	—	—	
	Packing (Tool side)	230077	XL0054-204	—	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	
Cable Accessories	Robot side	140168	OX-DS09-H	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	○※1	○※1	
	Tool side	140167	OX-DS09-I-H	—	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	—	
	Robot side	140197	OX-DS09S-H	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	○※1	○※1	
	Tool side	140247	OX-DS09S-H(1.5M)	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	○※1	○※1	
	Tool side	140202	OX-DS09P-I-H	—	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	—	
		140364	OX-DS09P-I-H(1.5M)	—	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	—	
	Robot side	140203	OX-DS09SL-H	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	○※1	○※1	
	Tool side	140248	OX-DS09SL-H(1.5M)	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	○※1	○※1	
		140204	OX-DS09PL-I-H	—	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	—	
	Tool side	140365	OX-DS09PL-I-H(1.5M)	—	—	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○※1	—	○	—	—	
	Connector Accessories	Robot side	140172	OX-DS09	—	—	○※2	—	○※2	—	○※2	—	○※2	—	○※2	—	○※2	—	○※2	—	—	—	○※2	○※2
Tool side		140171	OX-DS09-I	—	—	—	○※2	—	○※2	—	○※2	—	○※2	—	○※2	—	○※2	—	○※2	—	—	—	—	
Robot side		140174	OX-DS15	—	—	—	—	○※3	—	—	—	—	—	—	—	—	—	—	—	—	—	—		
Tool side		140173	OX-DS15-I	—	—	—	—	—	○※3	—	—	—	—	—	—	—	—	—	—	—	—	—		
Robot side		140304	OX-DS15-WS	—	—	—	—	—	○※3	—	—	—	—	—	—	—	—	—	—	—	—	—		
Tool side		140305	OX-DS15-I-WS	—	—	—	—	—	—	○※3	—	—	—	—	—	—	—	—	—	—	—	—		
Connector plate		140289	OX-DS09CNP	—	—	○※2	○※2	○※2	○※2	○※2	○※2	○※2	○※2	○※2	○※2	○※2	○※2	○※2	—	—	○※2	○※2		
Robot side		140303	OX-DPS09WCNP	—	—	—	—	○	○	—	—	—	—	—	—	—	—	—	—	—	—	—		
		140324	OX-DPS09A	—	—	○	—	○※4	—	○	—	○	—	○	—	○	—	○	—	—	—	○	○	
Tool side		140325	OX-DPS09A-I	—	—	—	○	—	○※4	—	○	—	○	—	○	—	○	—	○	—	—	—	—	
Robot side		140361	OX-PS15	—	—	○	—	○※4	—	○	—	○	—	○	—	○	—	○	—	—	—	○	○	
Tool side		140360	OX-PS15-I	—	—	—	○	—	—	○※4	—	○	—	○	—	○	—	○	—	—	—	—	—	
Robot side		140286	OX-PLA-07	○	—	○	—	○※4	—	○	—	○	—	○	—	○	—	○	—	—	—	○	○	
Tool side		140285	OX-PLA-07-I	—	○	—	○	—	—	○※4	—	○	—	○	—	○	—	○	—	—	—	—	—	
Robot side	140190	OXR-DPS09	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—	—		
Tool side	140192	OXR-DPS09-I	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—		
Wireless connector	Robot side	140306	OX-RS04R-SB	—	—	○	—	—	—	○	—	○	—	○	—	○	—	—	—	—	—	—	—	
	Tool side	140307	OX-RS04T-SBI	—	—	—	○	—	—	—	○	—	○	—	—	○	—	—	—	—	—	—		
	Robot side	140321	OXR-RS04R-10	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—	—	—		
	Tool side	140323	OXR-RS04T-10I	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—		
	Robot side	140308	OX-RS12R-LB	—	—	—	—	—	—	—	○※5	—	○※5	—	○※5	—	—	—	—	—	—	○※5	○※5	

* 1 If you use a cable accessory with no connector, you will need the proper D-sub & probe connectors(★ mark).

* 2 To install the D-SUB connector (140172, 140171), use the connector plate (140289) OX-DS09CNP as a set.

* 3 The D-SUB connectors (140304) OX-DS15WS, (140305) OX-DS15-I-WS, (140174) OX-DS15, and (140173) OX-DS15-I are dedicated to the OX-WSB・WSB I type.


* 4 The connector plate (140303) OX-DPS09WCNP is required for mounting on the type without a connector.

* 5 Because of the thickness of the wireless connector, it will come out or same as the mounting surface of the tool changer, please confirm the size.


				Air option														
				Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side	Robot side	Tool side			
				Order code No.	140294	140295	140193	140194	140251	140252	140195	140196	140253	140254	140287	140288		
Maintenance parts	Barbed joint		Order code No.	TYPE	OX-SSBA	OX-SSBIA	OX-SBA	OX-SBIA	OX-SBA1	OX-SBIA1	OX-LBA	OX-LBIA	OX-LBA1	OX-LBIA1	OX-LBA3	OX-LBIA3 ※		
			110623	LX0004-101	—	—	—	○	—	—	—	—	○	—	—	—	○	
			230116	XL0054-106A	—	○	—	—	—	—	—	—	—	—	—	—	—	
	Steel ball		110686	LX0120-202	—	—	—	—	—	○	—	—	—	—	○	—	○	
			323000	φ6.35	—	—	—	○	—	—	○	—	—	—	—	○	—	
			310607	φ5.5	○	—	—	—	—	—	—	—	—	—	—	—	—	—
	Coil spring		110649	L00999-420	—	—	—	—	—	—	—	—	—	—	—	—	—	
			185221	SAWANE5115	○	—	—	—	—	—	—	—	—	—	—	—	—	—
			110619	L00999-316	—	—	—	○	—	—	—	○	—	—	—	○	—	—
	Packing (Robot side)		200223	UR5-10	○	—	—	—	—	—	—	—	—	—	—	—	—	
			184474	S6 (C00503-A00X8)	—	—	—	○	—	—	—	○	—	—	—	○	—	—
			271742	1ASS-5	○	—	—	—	—	—	—	—	—	—	—	—	—	—
	Packing (Tool side)		110551	L00999-313	—	—	—	○	—	—	—	○	—	—	—	—	○	
			230077	XL0054-204	—	○	—	—	—	—	—	—	—	—	—	—	—	—
			110687	LX0120-203	—	—	—	—	—	—	○	—	—	—	○	—	—	○

※ (140288) OX-LB I A3 [for M5 port: (110623) LX0004-101+(110551) L00999-313, for M6 port: (110686) LX0120-202+(110687) LX0120-203]


OX-SSB/SSBI



OX-SB/SBI



OX-WSB/WSBI



OX-WLB/WLBI

